

Control Bar Status

Generated By : 11.0 End User (celinadoyle@att.net)

Generated On : 2023-01-19 18:34:09

Content Last Revised : 2019-02-21 20:49:55

Source : <https://docs.mmodal.com/direct>

Confidential Disclaimer : All information methods and concepts contained in or disclosed by this document is confidential and proprietary to MModal Services Ltd. By accepting this material, the recipient agrees that this material as well as the information and concepts contained therein will be held in confidence and will not be reproduced in whole or in part without express written permission from MModal Services, Ltd. Client use of M*Modal tools or information (excluding any services or tools provided to the Client that are covered under a separate written agreement) is subject to the terms of a legal agreement between the Client and M*Modal.

Corporate Address : 5000 Meridian Blvd #200, Franklin, TN 37067

Support Hotline (24/7) : 1-888-DICTATE (888-342-8283)

Support Email : fluency.direct@mmodal.com


Sales : 1-866-542-7253

Visual Feedback on the Control Bar

The Control Bar will display a variety of colors based on the status of the microphone and/or the connector; as well as your configuration. This is a quick visual cue for the user to know when to begin speaking or if there is an issue with the microphone.




Green = Recording and Connector working correctly (if applicable)



Red = Cannot record because microphone cannot be found or there is a severe problem accessing the appropriate recognizer. A red error state is unrelated to the Connector state and has been an available error state in Fluency Direct in most legacy versions. It is possible that a local recognizer is not available/found/installed if recognition is configured to process locally. Red could also indicate that Fluency Direct cannot access Remote Recognition servers (if configured to process remotely) or those servers are at maximum capacity in terms of connections.

Connectivity Issues



With 10.0.300 and higher, the Control Bar's record button will now visually indicate success or failure with the Connector connectivity.



Blue = Recording and Connector is not found/running in the Citrix XenApp, Terminal Services Server, or VMware session



Yellow = Recording and there's an incorrect installation on the client. Either the Citrix Receiver or Remote Desktop Client do not have the correct virtual drivers installed as part of FD. This could happen if the Citrix Receiver isn't restarted after install or if a new install of the Citrix Receiver was done and a Fluency Direct self-heal was not possible.

Written by **Cari**  Created: 13 March 2018  Last Updated: 21 February 2019